
TECHNICAL DATA SHEET

EQUA SUPREME Waterborne Coating

PRODUCT DESCRIPTION

Equa Supreme is an eco-friendly waterborne coating designed for residential and light commercial wood parquet flooring. It is a self cross linking single component polyurethane, upon curing after 7 days provide exceptional hardness to withstand heavy traffic in most condition. Unlike other waterborne coatings that appear amber, *Equa Supreme* is less yellowing which is highly desirable for white or bleached wood. It has exceptional flow and leveling ability, making it an extremely easy product to apply, exhibiting a mark free finish.

CAN BE USED FOR:

- Interior wood application on parquet flooring
- Skirting
- Handrails
- Doors
- Wall Panels

CHARACTERISTIC

Color: Translucent, clear upon curing
Odor: Non-offending when wet, none upon curing
Chemical Resistance: Resistant to most household chemicals
Gloss: Available in Matt, Satin, Semi Gloss and Gloss
Washing: Clean brush and equipment with water

TECHNICAL SPECIFICATIONS

Dilution: Ready to use, dilution not recommended
Viscosity: 45 seconds, BS4 cup (viscosity of gloss coating is lower)
Solid Content: 32% by weight
Density: 1.02 kg/L
Coverage: 120 to 150 square feet per kg
Drying time (approx): Dust Free – 10 mins, Print Free – 15 mins, Sanding – 60 mins.
Shelf Life: 12 months in closed container
Packing Size: 5 kg

HEALTH AND SAFETY

This product is not hazardous. As with all industrial chemical products, ingestion or prolonged skin contact should be avoided. Wash thoroughly with water when in contact with product.

SURFACE PREPARATION FOR OLD FLOORS

Ensure floor is free from wax and oily residue. Fill cracks, gaps and pin holes with Colorfil waterbone wood putty. Abrade with no.240 sandpaper to a smooth finish. Vacuum floor thoroughly and wipe with damp cloth to make sure floor dust is dust free.

SURFACE PREPARATION FOR NEW FLOORS

Fill cracks, gaps and pin holes with Colorfil waterbone wood putty. Sand floor with no.180 sandpaper to a smooth finish. Vacuum floor thoroughly and wipe with damp cloth to make sure floor dust is dust free.

COATING APPLICATION

1. **Apply first coat *Equa Supreme* coating with fine bristle brush, sponge or roller.**
2. **Allow 60 mins. Of drying time**
3. **Light sanding with no.280 sandpaper**
4. **Repeat step 1 to 3**
5. **Apply third coat of *Equa Supreme* with fine bristle brush for ideal final finish**

For areas with heavier traffic allow 4 or more coats of *Equa Supreme* for better protection.

The technical data contained herein is based on our present knowledge and experience and we cannot be held liable for any errors, inaccuracies, omissions or editorial failings that result from technological changes or research between the date of issue of this document and the date the product is acquired. Before using the product, the user should carry out any necessary tests in order to ensure that the product is suitable for the intended application. Moreover, all users should contact the seller or the manufacturer of the product for additional technical information concerning its use if they think that the information in their possession needs to be clarified in any way, whether for normal use or a specific application of our product. Our guarantee applies within the context of the statutory regulations and provisions in force, current professional standards and in accordance with the stipulations set out in our general sales conditions. The information detailed in the present technical data sheet is given by way of indication and is not exhaustive. The same applies to any information provided verbally by telephone to any prospective or existing customer.